

PYRAMID 
CBF1000 06-10 HUGGER

General Information.

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the Hugger should sit centrally over the tyre when viewed from the rear. The tolerance in the right hand side mounting bracket allows adjustment to achieve this. As with all accessories the mountings should be checked for tightness.

Fitting kit:

2 x M6 x 12mm allen bolt
2 x M6 plastic washer

Fitting instructions:

- 1) Undo two large Allen bolts near gear selector on left hand side and lower the exhaust to gain access to front chain guard bolt.
- 2) Remove chain guard.
- 3) Slide the hugger in from left side rear and loosely attach with bolts and washers provided on chain guard side.
- 4) Remove brake hose bolt and locate hugger underneath brake hose clip and re-attach using original bolt.
- 5) Align the hugger by gently lifting the rear and tighten the chain guard bolts.